
INTRODUCTION

Thank you for choosing this Johnson amplifier. Please read this manual carefully and completely before operating your new amplifier.

PANEL FUNCTIONS



- 1 INPUT
 Used to connect the signal output from an electric guitar.
- OVERDRIVE-DEPTH
 Used to adjust the amount of distortion according to the performer's needs.
- 3 OVERDRIVE-SELECT
 Used to control the OVERDRIVE-SELECTOR switch. In the "in" position, the input signal is routed to the overdrive channel. In the "out" position, the input signal is routed to the clean channel.
- 4 OVERDRIVE-MASTER

 Controls the volume level of the OVERDRIVE function.
- 5 VOLUME
 Controls the volume level of the clean channel (without overdriving).
- 6 TREBLE BAND
 Used to shape the amplifier's tone by adjusting the high-end frequencies.
- MIDDLE BAND Used to shape the amplifier's tone by adjusting the middle frequencies.

8 BASS BAND

Used to shape the amplifier's tone by adjusting the bass frequencies.

9 PRESENCE

Reduces or increases frequency attack and brightness, particularly in the mid to high-end frequencies.

10 SPRING REVERB

Used to adjust the level of reverberation/reflection effect.

11 headphone

Used for private listening. Uses a 1/4" jack connector. (Speaker disengaged when headphone jack is in use.)

12 power on/off indicator

LED glows when the unit is turned on.

13 POWER SWITCH

This switch turns the unit ON and OFF.

14 fuse socket

Only replace the fuse with one that has correct value and size.

15 EFFECT LOOP-RETURN


Used to receive signal from an external effects device.

16 EFFECT LOOP-SEND


Used to send out the signal to an external effects device.

SUGGESTED SETTINGS


Clean -




Heavy Rock Rhythm



Rock



Blues



TECHNICAL SPECIFICATIONS

POWER SUPPLY 110/115VAC/50Hz~60Hz

POWER OUTPUT: 20 watts RMS @ 8 ohms

LOAD IMPEDANCE: 8 ohms

INTERNAL SPEAKER SYSTEM: 7.7" diameter

EQ SECTION

Bass Control Range: +3dB/-19dB@100Hz
Mid Control Range: +8dB/-5dB@1kHz
Treble Control Range: +18dB/-7dB@10kHz

DELAY CHARACTERISTICS:

Spring Style Reverb

SIGNAL TO NOISE RATIO: $S/N \ge 70 dB$

INPUT: 1/4" Mono Jack

LINE OUTPUT: 1/4" Mono Jack

RETURN: 1/4" Mono Jack

DIMENSIONS: $14''(W) \times 14.2''(H) \times 7.9''(D)$

WEIGHT (approx.): 16.5 lbs.

PRECAUTIONS

POWER SOURCES

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company.

INSERTION WARNING

Never place objects of any kind into this product as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

SERVICING

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

HEAT

The product should be placed away from heat sources, such as radiators, heat registers, stoves, or other products that produce heat.

CLEANING

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

SAFETY CHECK

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

SAFETY PRECAUTIONS

WARNING

CAUTION: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS AMPLIFIER TO RAIN OR MOISTURE. DANGEROUSLY HIGH VOLTAGE IS PRESENT INSIDE THE ENCLOSURE. DO NOT OPEN THE CABINET. REFER SERVICING TO QUALIFIED PERSONNEL ONLY.



This symbol warns the user of dangerous voltage levels localized within the enclosure.



This symbol advises the user to read all accompanying literature for safe operation of the unit.



WARRANTY INFORMATION

This amplifier is warranted, to the original Purchaser, to be free from defects in material and workmanship for a period of five (5) years from the original retail purchase. This warranty is valid in North America only.

The manufacturer shall, at its option, either repair or replace the defective product if the product is returned to the original place of purchase. If any product returned is not defective within this warranty, the manufacturer shall so advise the Purchaser and thereafter shall dispose of said product in accordance with the Purchaser's instructions and at the Purchaser's cost. This warranty is not transferable by the Purchaser.

The warranty shall not apply to wearable parts, these items include, but are not limited to, amplifier knobs, feet, and handles.

This warranty shall not apply if the product has been misused or damaged as a result of neglect, abuse, alteration, improper handling, unauthorized repair or modification, accident or causes external to the product, such as, but not limited to, excessive heat or humidity.

The manufacturer's sole and exclusive maximum liability for any claim by the Purchaser, shall not exceed the wholesale value of the product. In no event shall the manufacturer be liable for any indirect, incidental, collateral, exemplary, or consequential damages or losses arising out of the Purchaser's purchase of the product. The above limitations may not apply in some states.

INSTRUCTION MANUAL

MODEL: 25-R



JohnsonTM

Stage Series Guitar Amplifier